



- Mounting solution, to avoid a collision of the earthing bar with the outriggers (profile holders).
- The red insulators for the earthing bar have to be mounted at the rear lateral raster holes at the 19" profiles, instead of outer one.
- Despite the 15 mm lower seat, the busbar clamps can still be attached from the front and rear.
- The earthing bar has 8 holes: 3 at each end and 2 inner holes. The second from the outside and the two inner holes are used for fastening.