

DATASHEET

Set of Captive Nuts, 50 x M6 for Front-Mounting

Art.-No. 691102



- For front-sided mounting into 19" profile
- Easy and fast - no more wounded fingers!
- Set of 50 x cage nut, 50 x screw M6 x 16, 50 x washer, black
- Material steel / nylon

Step 1



Insert the cage nut from front-side into the cutout of the profile

Step 2



Fix the plastic housing by doing a quarter turn to the right

Step 3



Insert and fix the screw M6 to fasten the thread element

Ordering Data

Art.-No.	Description
691102	Set of Captive Nuts, 50 x M6 for Front-Mounting (50 x Captive Nut, Screw, Washer)



Art.Nr.	691102	Datei	691102.indd		
Beschreibung	Käfigmutterset 50 x M6 zur Frontmontage				
Erstellt	Datum	Letzte Revision	Datum	Geprüft	Datum
MN	22.02.2018	MN	22.02.2018	MN	22.02.2018